

# Design of roofs Dach+

## Table of contents

Possible applications	2
Input	5
Wizard	5
Basic parameters	5
System	6
General	6
Geometry	6
Support	8
Cross-sections	9
Loading	10
Dead Load	10
Snow and wind	10
Load cases	11
Standard Load Cases	11
Additional Load Cases	12
Design	14
Design settings	14
Connection Details	16
Calculation	17
Output	18

*Note: this program with its licensable options is the successor to the previous roof programs D9 - Continuous Rafter, D11 - Purlin and Rafter Roof, D12 - Collar Beam Roof - DGK Hip Rafter / Valley Rafter.*

## Basic documentation - overview

In addition to the individual program manuals, you can find basic explanations on how to operate the programs on our homepage [www.friilo.eu](http://www.friilo.eu) ( ▶ Service ▶ Articles Information ▶ Basic Operating Instructions).

Farther documents:

[Roof-Loads-Design](#)


[Fire protection analysis timber](#)

## Possible applications

Dach+ calculates according to the licensed option

- Continuous rafters,
- Pent roof rafter,
- Purlin roof
- Rafter roof,
- Collar beam roof,
- Hip rafter,
- Valley rafter.

The roof or rafter type is selected from a selection list in the [Wizard](#) right at the beginning.



**Wizard**

Create new structural item

Wizard    Templates    Open

Common

Roof / Rafter type	Continuous Rafter	
Selection of town	Continuous Rafter	
Dead Load ( Roofing)	g1	Purlin Roof
Ground Snow Load	sk	Rafter Roof
Wind pressure	qp,0	Collar Beam Roof
Wind pressure	qp,90	Hip rafter
		Valley rafters

Material

Timber	Softwood	
Material code	EN 338:2016	
Strength class	C24	
Service class	2	

Cross-section

Width	b [cm]	10.0
Height	d [cm]	20.0

System

Rafter Spacing	e [cm]	100.0
Rafter Slope	$\alpha$ [°]	30.0
Rafter Length	[m]	7.00
Number of spans		2

OK    Cancel

### Standards

- EN 1995:2008/2014
- DIN EN 1995:2010/2013
- ÖNORM EN 1995:2010/2015/2019
- UNI EN 1995:2007
- NTC EN 1995:2008/2018
- BS EN 1995:2012/2019
- PN EN 1995:2010

DIN 1052:2008 is also available.

## Options S / P / K / GK

### Dach-S option: Continuous Rafter or Pent Roof Rafters

With this option, single and multiple span continuous rafters can be calculated and designed as a single component. Cantilever arms are possible on both sides.

### Dach-P option: Purlin and Rafter Roof

With this option, purlin roofs and rafter roofs as well as mixed constructions of both systems can be calculated, e.g. purlin roofs with ridge joint. The rafters on the left and right are designed as continuous bending beams.

### Dach-K option: Collar Beam Roof

Calculation of collar beam roofs with movable / fixed collar beam.  
The collar beam can consist of one or two parts.

### Dach GK option: Hip and Valley Rafter

Calculation of hip rafters and optionally valley rafters.

## Systems Dach-P / Dach-K

- The roof halves can have different roof pitches
- The purlins can be at different heights
- The left and right halves of the house can be of different widths
- Horizontal and vertical bearings can be rigid, spring-loaded or movable

## Loads

- Area loads, weight, snow and wind loads
- Additional loads as uniform, single or trapezoidal loads
- Man loads and wind currents in overhangs

## Calculation

The system is treated statically as a framework system, taking into account the normal force deformations and the effect of the real, specified support conditions.

All load combinations are calculated and designed according to the applicable combination regulations.

## Design settings

Optionally selectable:

- proof against wind suction (see also document [Roof Loads-Design](#))
- earthquake combinations
- fire design

For the permissible span/cantilever deflections of the respective verifications (based on the length L), the recommended values of the respective standard are preset as standard. These can be customized.

Since the negative deflection there usually determines the design result in the case of short cantilevers, this often undesirable influence can be optionally eliminated with the option "only positive deflection on cantilevers".

### Proofs of stability

For the proof of stability, a continuous tilt bracket and continuous lateral support are used as standard and the buckling length in the rafter level is limited to  $0.9 \cdot \text{component length}$ .

These boundary conditions can be adapted individually.

There are various options available for determining the stability lengths.

For each superposition, the associated effective lengths for the individual bars are determined from the eigenvalue solution. Due to numerical problems, however, the effective lengths of bars with a low normal force can be too great.

For precisely such cases, there is the option of limiting the buckling length to a maximum value.

Optionally, the buckling and tilting lengths can be specified individually for each bar.

Alternatively, the buckling/tilting length can always be set to the bar length, component length or a specified value.

### Serviceability

The serviceability verification is carried out according to the rules of EN 1995-1-1 with initial and final deformation and consideration of creep deformation.

### Support forces

Support forces are output as characteristic maximum values and sum per action.

Characteristic support forces are transferred to the subsequent components for each load case, for which the decisive combinations are then created in the program called up.

In addition, the load cases per individual load case and the superpositions can optionally be output.

### Load Forwarding / Associated Programs

The bearing loads can (with Roof-S /P/K) be passed on to the multi-span timber beam HTM+.

See also document [Roof Loads-Design](#).

The interface to the RSX Framework enables an alternative calculation.

Entered [connection details](#) (rafter base point) can optionally be passed on to the corresponding toolbox module for calculation (the corresponding item "TB Toolbox" is then displayed here).

### SEMA import/export

".sema" files can be imported/exported via File ► Import or Export.

Find out more about this in the SEMA manual.

## Input

### General information on the input fields

This program can be used to calculate according to various standards or national annexes. These standards differ considerably in terms of load approaches, combination rules, determination of the decisive internal forces and verification.

The input fields and selection options described below can therefore differ from one another depending on the selected standard.

## Wizard

After starting the program, the [wizard](#) opens automatically, with which you can quickly and easily create a calculable basic system.

Here you select the type of roof or rafter: continuous or pent roof rafters, purlin or collar beam roof, hip and valley rafters.

Furthermore, the necessary/most important parameters are queried here.

An item can then be further developed on this basis.


*Note: the other roof types can also be called up using the "Other roof types" button in the upper menu ribbon.*


## Basic parameters

Selection of the standard and the material. You can also enter the strength and service class as well as the specific weight here.

### Strength class

The strengths and stiffnesses can be adjusted. To do this, click in the input field and press the F5 key. You can enter/edit/save/load new material in the "User-defined material" pop-up menu.



Basic parameters	
Design code	 DIN EN 1995:2013
Consequence class	2
Ductility class	Low
Material	
Timber	Softwood
Material code	EN 338:2016
Strength class	C24
Service class	2
Specific weight	$\gamma$ [kN/m <sup>3</sup> ] 6.00

## System

*Note: the following entries differ depending on the selected roof or rafter type.*

### Remarks

You can enter [remarks about the system](#) that optionally appear in the output.

### General

Here you define the other properties depending on the selected roof type.

Rafter spacing	Center distance of the rafters
Rafter type	Choice of continuous or pent roof rafters
Symmetrical	Symmetrical or asymmetrical roof
Ridge connection	Rigid, pinned or open
With ridge purlin	Yes/no
With collar beam	Yes/no

### Geometry


Depending on the selected roof type and symmetry, the appropriate input fields are displayed.

#### Rafters (left / right)


- Slope  $\alpha$  The angle of slope of the rafters - can also be changed directly in the graphic.
- Number of fields Up to 5 fields/sections are possible.
- Span 1, 2 ... Lengths of the individual spans. Span 1, Span 2, etc.
- Cantilever Length of the cantilever.
- Overhangs Definition of a free roof overhang.  
The overhang plays a role above all for the approach of wind [underneath currents](#), but also for the consideration of the extension loads.  
Overhang = start of the rafter to the edge of the house.

#### Collar beams

- Distance to the ridge Distance of the collar beam to the ridge.
- Collar Beam Length Display of the calculated collar beam length.
- Number of fields Up to 4 fields with different lengths (field 1, field 2 ...) are possible.
- Fixed If the option is marked, the collar beam roof cannot be moved, otherwise it can be moved.
- With support Optional supports at the collar beam ends.



Properties		
Basic parameter		
System		
Common		
Geometry		
Support		
Cross-sections		
Loading		
Design		
Output		
Rafter Spacing	e [cm]	100.0
Symmetric		<input type="checkbox"/>
Connection of Ridge		Pinned
With purlin at ridge		Rigid
		Pinned
With collar beam		Open



Properties		
Basic parameter		
System		
Common		
Geometry		
Support		
Cross-sections		
Loading		
Design		
Output		
Rafter left		
Slope	$\alpha$ [°]	30.0
Number of fields		1
Span 1	L,1 [m]	5.00
Cantilever bottom	L,btm [m]	0.00
Overhang bottom	L,btm [m]	0.00 <input type="checkbox"/>
Rafter right		
Slope	$\alpha$ [°]	30.0
Number of fields		1
Span 1	L,1 [m]	5.00
Cantilever bottom	L,btm [m]	0.00
Overhang bottom	L,btm [m]	0.00 <input type="checkbox"/>
Collar beam		
Distance to the ridge	[m]	0.96
Collar Beam Length	[m]	3.33
Number of fields		1
Fixed		<input type="checkbox"/>
With support at left		<input type="checkbox"/>
With support at right		<input type="checkbox"/>

## Hip or valley rafters

Various input options are available for defining the roof envelope. The dimensions/values are displayed in the graphic for checking and can also be changed there directly.

### System limits

Type

#### Single span system:

the simplest entry with a 90-degree angle, without span subdivisions, cantilever arms, floor plan angles, etc.

#### Right-angled and symmetrical:

As with the single-span system, however, the top can be subdivided into spans as a result of purlins. Both sides are symmetrical. The input fields for the shift rafters can be expanded.

#### Right-angled:

an asymmetrical span division is possible here.

#### Floor plan angle freely selectable:

as right-angled, in addition, the input field for the plan angle can be edited.

#### Crippled hip-like:

A one-sided overhang is also offered here


(→ greater length of the shift rafters for the load introduction area).

#### At right angles over heights and lengths:

Input about the height and projection length of the marginal planes.

#### At right angles across heights and angles:

Input about the height and angle of the marginal shift planes.



The screenshot shows the 'Properties' panel on the right side of the software interface. The 'System' tab is selected, and the 'Geometry' sub-tab is active. Below the 'System borders' section, there are two expandable sections: 'Jack Rafter Main Roof' and 'Jack Rafter Adjacent Roof'. Each section contains input fields for 'Cantilever bottom', 'Cantilever top', 'Number of fields', and 'Span 1'. The 'System borders' table is also visible, showing various parameters and their values.

System borders	
Type	Right-angled
Angle in floor plan	Single span system Right-angled and symmetrical Right-angled
Main roof pitch	Floor plan angle freely selectable Crippled hip-like Overhang on both verges
Main roof base length	At right angles across heights and lengths Right angles across heights and angles
Adjacent Roof Pitch	
Adjacent roof Base length	
Height of ridge hipped/valley [m]	1.73
<b>Jack Rafter Main Roof</b>	
Cantilever bottom	[m] 0.00
Cantilever top	[m] 0.00
Number of fields	1
Span 1	[m] 3.00
<b>Jack Rafter Adjacent Roof</b>	
Cantilever bottom	[m] 0.00
Cantilever top	[m] 0.00
Number of fields	1
Span 1	[m] 3.00

Angle in the floor plan	The angle between the eaves is illustrated in the graphic and can also be changed there directly.
Main roof pitch	Angle of slope on the main or secondary roof.
Main roof base length	Basic length in the direction of the main roof or the secondary roof.
Main roof projection length	edge shifters With the type "right-angled over heights and lengths/angles, the projection lengths for the main and secondary roofs are entered here.
Ridge height	Informative display or changeable value for the height of the ridge.
Main roof overhang	Overhang on the hipped roof.


### Schifters rafters (main or secondary roof)

Cantilever	Length of the cantilever arms above or below.
Number of fields	Die Eingabe von bis zu 3 Feldern ist möglich.
Span 1..3	Length of the individual spans.

## Support

In the Common section, to simplify the entry, you can specify whether the same (standard) mouth depth should apply to all supports or whether you want to enter this value yourself (then check the box) and whether the horizontal and vertical supports should all be rigid.

Depending on the selected roof type, you can call up the corresponding support tables.


Call up the support table(s) via the table symbol  or via the tab below the graphic.

The horizontal and vertical supports are entered. If the option is marked, the support is rigid. To enter a custom value, remove the check mark.

An (optional) mouth or incision depth [cm] weakens the rafter cross-section in the support areas.

**Active** With hip/valley rafters, the supports are created automatically as a result of the purlins of the shift rafters - if you do not want this, you can set the supports inactive using this option (you can find the option in the table entry under the tab "Supports due to purlins").

**Additional supports** In the case of hip/valley rafters, additional supports (e.g. as a result of supports) can be created in the table using the "+" symbol.




Left RafterSupport			
No.	Horizontal Support	Vertical Bearing	Depth of Birth Mouth
	[kN/m]	[kN/m]	[cm]
1	2	rigid <input checked="" type="checkbox"/>	rigid <input checked="" type="checkbox"/>
			0.0

Fig. : Tab under the graphic.

## Connection details of the rafter base points

The functions/dialogs for the rafter bases can be called up via the context menu of the supports.




Via "Connected programs" (in the menu above), the connection details can optionally be forwarded to the corresponding toolbox module (rafter base) for calculation.

See also Design ► [Connection Details](#).



## Cross-sections

Number	Number of cross-sections (1 or 2).
Width/Height	Display of the selected or input of the cross-section dimensions.
Different cantilever	If necessary, other cross-sections than for the rafters can be selected for the cantilever arms. Check this option to display the corresponding input fields.



Rafter left			
Number	1		
Width	b	[cm]	10.0
Height	d	[cm]	20.0
Different cantilever			<input type="checkbox"/>
Rafter right			
Number	1		
Width	b	[cm]	10.0
Height	d	[cm]	20.0
Different cantilever			<input type="checkbox"/>
Collar beam			
Number	1		
Width	b	[cm]	10.0
Height	d	[cm]	20.0

## Loading

See also document [Roof Loads-Design](#).

### Dead Load

Dead weight autom. Here you choose whether you want to calculate with or without dead weight.

#### Rafter

g1/g2/g3

The loads "g1" and "g2" act over the entire length of the rafter. Your load coordinates are related to the roof area. The loft conversion load "g3" acts from the edges of the house ground to the ridge or between the edges of the house ground.


Loft conversion bottom gb The program applies the lower load on the collar beam roof between the bottom support and the collar beam.

Roof payload (man load) No or only single load.

PV-system Photovoltaic system: select this option to show the corresponding parameters.

#### Collar beam

Both permanent loads gk and live loads pk can be specified for collar beams. The live loads are assumed to be one-sided for the asymmetrical load cases.



Settings			
Dead weight automatically			<input checked="" type="checkbox"/>
Rafter			
Roofing	g1	[kN/m²]	1.00
construction	g2	[kN/m²]	0.00
Loft conversion	g3	[kN/m²]	0.00
Loft Conversion bottom	gb	[kN/m²]	0.00
Roof payload (man load)	single load only		
PV-system left		[kN/m²]	0.00 <input type="checkbox"/>
PV-System right		[kN/m²]	0.00 <input type="checkbox"/>
Collar beam			
Persistent load	gk	[kN/m²]	0.60
Live load	pk	[kN/m²]	1.50
Action	Cat. A: domestic, i		

## Snow and wind

### Basic values

Basic values This button opens the snow and wind load dialog.

Town selection Display of the municipality selected under "Base values". If you would like to enter your own values instead, uncheck this option and enter the values below.

### Boundary conditions for snow loads

Snow skirt and snow accumulation can be selected left and right. Since the factors for exceptional snow loads can differ between the National Annexes, the *Cesl* value can be modified if necessary.



### Boundary conditions for wind loads

Ridge height Height of the ridge above the terrain.

Roof length Roof length as the width of the wind attack b.

Building length Building length as the length of the wind attack for walls.

Approach wind Pressure and suction alternatively, only pressure, only suction.


Basic Values			
Land for loads		 Germany	<input type="checkbox"/>
Basic Values			
Town selection			<input type="checkbox"/>
height of terrain	Altitude	[m]	0.00
Snow action group	Snow loads H < 1000 m		
Ground Snow Load	sk	[kN/m²]	1.00 <input checked="" type="checkbox"/>
Wind pressure	qp,0(h)	[kN/m²]	1.00 <input checked="" type="checkbox"/>
Wind pressure	qp,90(h)	[kN/m²]	1.00 <input checked="" type="checkbox"/>
Boundary conditions for snow loads			
With snow guard left			<input type="checkbox"/>
With snow accumulation left			<input type="checkbox"/>
With snow guard right			<input type="checkbox"/>
With snow accumulation right			<input type="checkbox"/>
With accidental snow	Cesl		2.30 <input type="checkbox"/>
Boundary conditions for wind loads			
Total ridge height	h	[m]	6.00
Length of Roof	b, Roof	[m]	20.00
Building length	b, Wall	[m]	20.00
Approach wind	Pressure and Suction alternate		
Loads for Calculation	Pressure and Suction alternate		
Load values acc.to code	Only pressure		
	Only suction		

**Wind range** With the ridge/valley rafter, you can optionally choose which wind range is to be used as the basis for the averaged wind load on the main/secondary roof. Otherwise the program automatically takes the area with the greatest wind pressure.

### Loads for Calculation

**Load values acc. to code** Deactivate this option to be able to enter your own values.

## Load cases

You can use the "to the table"  symbol or the tabs under the graphic to access the tables for the standard load cases or the additional load cases.


### Settings

**Equal  $\gamma_G$  for permanent loads** If the option is selected, permanent loads are also combined, otherwise they are all applied the same.

**...as dependent load cases** If the option is selected, the loads are assumed to be "dependent" and combined. Note that when you choose a dependency, you must ensure that the loads always occur together at the same time!

**Live load on Collar Beam ...** If the option is selected, the live load on the collar beam is considered independently span by span.

**Omit opposing ...** If the option is selected, standard load cases/combinations with loads whose expected deformations are in opposite directions are omitted.



## Standard Load Cases

Wind and snow loads are automatically generated as "Standard Load Cases" in accordance with the applicable standards. These load cases can be switched on and off in the table individually or as a whole in the "Active" column, but they cannot be edited.


"Standard load cases" can be copied to ["Additional load cases"](#) and edited there ("Copy all snow, wind, man load cases").

To display the table, click on the "Standard Load Cases" tab below the graphic.

## Additional Load Cases

Here you can create your own load cases or copy "Standard Load Cases" in order to add or change them.

Note: for a new table row click on the right  symbol.



**Name** Enter a (own) load case name.

**Short Name** Enter a short name, eg for display in tables.

**Action** Selection of the action from a list.


**Alt. group** Load cases to which you assign the same alternative group number (>0) do not act simultaneously (but rather "alternative"). Example: Wind loads from different directions.

**Remark** Free comment text.

**Active** Load cases can be set temporarily inactive here (remove tick).  
During the calculation, all load cases marked as "active" are automatically superimposed according to the applicable combination rules, taking into account the alternative groups.

**Copy from load case** Here you can select previously entered load cases. The selected load case is then copied and can then be edited/adjusted.

**Loads** With this button you call up the input table of the loads for the load case.



**Relation** Reference for the load: line load (component-related) or area load (area-related).

**Member** Component: Rafters left, right, collar beam.

**Load type** Single load  
Uniform load (continuous or in sections)  
Trapezoidal load (continuous or in sections)

**Orientation** Load alignment depending on load type:  
Point load:  
- vertical (global down)  
- horizontal (global)  
- transverse (to the member axis)  
- longitudinal (in the direction of the member axis)

Line load:  
- vertical to beam (global down on member)  
- vertical to projection (global down on projection)  
- transverse to the beam (perpendicular to the member axis)

**Dist.** Specifies the distance of the load in x-direction from the start of the component.

**L** Specifies the length of the line load in x-direction.

**W1, W2** Load value at the beginning or at the end of the line load.

A load value compilation can be called up using the "arrow symbol" 

Factor        The load value is multiplied by this freely definable factor.

Remark       Optional entry of free text.

See also document [Roof Loads-Design](#).

## Design

### Design settings

#### Calculation rules

- Only positive deflection on cantilever arms

For short cantilever arms the negative deflection there usually determines the design result, this often undesired influence can be eliminated by selecting the option "Only positive deflections on cantilever arms".

- The reference length for the total deflection

For the serviceability verifications, you can specify whether the member or the component length should be taken into account as the reference length for the total deflection design.

For the local (member-by-member) deflection verification, the member length is always automatically used as the reference length.

- kmod Wind averaged

If the option is selected, the kmod coefficient for wind is used as the mean value for the classes of load durations short and very short.

- With equilibration check

If the option is checked, proof against withdrawal is provided. The  $cpe1$  values are used as a basis for determining the wind loads. The verifications are carried out in the design situation "Equ".

The case that the load application area of the rafter is underflowed by the wind like a cantilever when the wind flows on the gable side can be taken into account with the option "With gable-side overhang".

- Influence of creep under pressure:

The influence of creep can optionally be taken into account as follows for components subject to compression:

- The stiffnesses should not be reduced as a result of creep.
- The stiffness should be reduced as a result of creep from a constant load component.
- The stiffness should be reduced as a result of creep from permanent and quasi-permanent load components.


#### Ultimate Limit State

- Fire protection design:

Check this option to display the input fields for the fire design. If this option is selected, the stress verifications are also carried out in the event of a fire.

- Check method:

- no defaults                      The program chooses the procedure
- Simplified method              Process with reduced cross-sections
- Exact method                    Process with reduced properties



The screenshot shows the 'Properties' tree on the left with 'Design settings' selected. The 'Calculation Rules' table on the right is as follows:

Calculation Rules	
Only positive deflections on cantilever	<input checked="" type="checkbox"/>
Reference length for total deflection	Member Length
kmod Mean wind	<input checked="" type="checkbox"/>
With equilibration check	<input type="checkbox"/>
Influence of creeping under pressure	Depending on per
Ultimate Limit State	
Fire design	<input checked="" type="checkbox"/>
Check method	no defaults
Fire resistance class	R 30
Charring all sides	<input checked="" type="checkbox"/>
Charring acc.to code	<input checked="" type="checkbox"/>
Buckling-/Tilt- Lengths	
Selected member	Rafter left
Cold Design	
Buckling in plane	limited from einge
limited to	L*
Buckling out of plane	Continuous fixed
Tilting	Member Length
	Member length
	from eigenvalue
	limited from eigenval
Fire Design	
Buckling in plane	Constant value
	Member wise user val
Buckling out of plane	Member length
Tilting	Member Length
Serviceability	
w <sub>inst</sub>	<input type="checkbox"/> 300
w <sub>net,fin</sub>	<input type="checkbox"/> 300
w <sub>fin</sub>	<input type="checkbox"/> 200

- Fire resistance class:

Selection of the desired fire resistance class or user-defined input of the burn time.

- Charring all sides:

Uncheck to select individual sides for fire exposure.

- Charring according to code:

Remove the tick if you want to specify the charring rates  $\beta_n$  for the individual sides yourself, otherwise the standard values will be used.

See also document [Fire protection analysis timber](#).

### Buckling and tilting lengths

- Selected member                      Selection of the component (rafter, collar beam).

### Cold Design

The boundary conditions for the buckling lengths in and out of the rafter plane as well as the tilting length or the lengths themselves can be specified separately for each component.

The following conditions are available:

- continuously fixed
- Buckling/tilting length = bar length
- Buckling/tilting length = component length
- from the determination of the eigenvalue for each load combination, optionally with an upper limit
- Specification of a constant value for each bar
- Specification of the values for each individual bar

In the event of a fire, the option of determining the eigenvalues is not applicable, since the cross-section values would vary depending on the design method for the individual verifications!

### Serviceability

w <sub>inst</sub>	Limit of elastic deflection
w <sub>net,fin</sub>	Limit value of the sum of elastic deflection and creep deformation
w <sub>fin</sub>	Limit of the final deformation



## Connection Details



Connection details of rafter base points

- nothing selected,
- with notch and threshold,
- with straight collar,
- with haunched collar.

With the Edit button you can open the corresponding dialog.

Optional forwarding of connection details to the toolbox (connected programs in the ribbon).

For graphical input, see also the "[Support](#)" chapter.






## Calculation

To calculate, click on the "Calculate" button in the upper menu bar.

### Auto calculation option

The option for automatic calculation after each input can be switched on under File - Settings if the runtime behavior of your computer is satisfactory, so that a new calculation can be carried out immediately with each input change.

For more information see the document [Roof Loads-Design: Calculation](#)



## Output

Before the output click on the symbol "Calculate" in the upper menu ribbon.

After the calculation, the utilization is displayed at the bottom right in the graphics window and offers a good overview of the economic efficiency of the system entered.

### Output profile

By clicking on the various output options, you determine the scope of the output.

### Results

You can view the result graphics via the "Results" tab in the upper menu ribbon.

Here you can also the options of scaling graphics and taking snapshots for the output.

### Output as a PDF document

The output document is displayed in PDF format via the „[Document](#)“ tab and can be printed.

See also document [Output and printing](#).

