

# BDU+ Flush Beam


FRILO Software GmbH

www.friolo.com

info@friolo.eu

As of 07/02/2017

Software version 1/2017





# BDU+ – Flush Beam

## Contents

<b>Application options</b>	<b>4</b>
<b>Bases of design</b>	<b>4</b>
<b>Data entry</b>	<b>5</b>
Basic parameters	5
Structural system	5
Loading	5
Design	6
<b>Output</b>	<b>9</b>
<b>Reference literature</b>	<b>9</b>

Further information and descriptions are available in the relevant documentations:

<a href="#">Basic Operating Instructions PLUS</a>	General instructions for the manipulation of the user interface of Frilo PLUS applications.
<a href="#">FCC.pdf</a>	Frilo.Control.Center - the easy-to-use administration module for projects and items
<a href="#">FDD.pdf</a>	Frilo.Document.Designer - document management based on PDF
<a href="#">Frilo.System.Next</a>	Installation, configuration, network, database
<a href="#">Menu Items FDC.pdf</a>	
<a href="#">Output and Printing FDC</a>	

## Application options

This software allows you to analyse girders fitted flush to the surface of reinforced concrete ceilings in accordance with EC2. The girder can be an intermediate support or an end support of the reinforced concrete slab. It can be pinned or restrained, either on the left, on the right or on both sides.

The software application performs the following separate calculations:

- Required bending reinforcement
- Required shear reinforcement
- Required transverse reinforcement in the support area

### Available standards

- DIN EN 1992:2012
- DIN EN 1992:2013
- DIN EN 1992:2015
- ÖNORM EN 1992:2011

## Bases of design

The bases of calculation are provided by DIN EN 1992-1-1 and its National Annex or ÖNORM B 1992-1-1 and by Booklet 240 of the German Committee for Reinforced Concrete (DafStb).

## Data entry

### Basic parameters

Select the standard, the design situation (permanent/transient, accidental) and the material.

Properties	
Basic Parameters	
System	
Loads	
Design	
Output	

Basic parameter	
Reinforced concrete code	DIN EN 1992:2015
Design situation	permanent/transient
Concrete	C 25/30
Reinforcement Steel	B500A

### Structural system

Type of support end support or intermediate support

Kind of support restrained or pinned

d slab thickness

t wall thickness

lp slab width

ln clear width

System	
Support art of the plate	End support
Support type, left	clamped
Support type, right	clamped
Plate thickness	d [cm] 20.0
Wall thickness	t [cm] 24.0
Plate-width	lp [m] 4.20
Clear width	ln [m] 2.40
Remarks	

### Loading

The loads are defined separately for g and q with their characteristic values.

You can define area loads and line loads.

The options allow you to select whether simplified load areas or load areas calculated with a load propagation below 60 ° should be used.

You can optionally include self-weight or exclude it.

Loading	
Inclusive dead-load	<input checked="" type="checkbox"/>
Distributed load - permanent	g [kN/m <sup>2</sup> ] 1.50
Distributed load - live	q [kN/m <sup>2</sup> ] 2.20
Line load - permanent	g [kN/m] 0.0
Line load - live	q [kN/m] 0.0
Simplified load area	<input type="checkbox"/>

## Design

Define first the [Durability](#) in a separate dialog.

...diameter select the bar/stirrup diameter from a list.

Actual concrete cover indication of the location of the reinforcing steel

Design as a plate: the default setting is the design of a beam as specified by the standard. When you check this option the shear reinforcement is designed as a plate.

Support moment in the support face when you check this option, the support moment is determined at the edge of the support (in the support face). When the option is unchecked, the moment is calculated in the system axis and the moment curve is radiused.

Reinforcement scheme presented on the graphic screen

Reinforcement			
Dauerhaftigkeit	ob = un: XC1/W0		
Reinforcement layer top	d1	[cm]	4.0
Reinforcement layer bottom	d2	[cm]	4.0
Rod diameter top			12
Rod diameter bottom			12
Stirrup diameter			8
Always check the concrete cover			<input type="checkbox"/>
Concrete cover top	cv.I	[cm]	3.4
Concrete cover bottom	cv.J	[cm]	3.4
With nominal reinforcement			<input checked="" type="checkbox"/>
Design like plate			<input checked="" type="checkbox"/>
Support moment on cut			<input checked="" type="checkbox"/>
Reinforcement schema			


The design of girders flush to the ceiling surface is performed in accordance with reference /3/ with a relation of the length of the missing support  $l$  to the slab thickness  $h$  of  $7 < l/h < 15$ . For beams that satisfy the condition  $l/h < 7$ , constructive reinforcement is sufficient, under normal conditions, and additional verifications are not required. For beams where  $l/h > 15$  and slabs where the support is discontinuous, additional verifications need to be performed.

The effective widths in the span area, in the support area and for the shear design are determined as follows:

	For interior supports	For slab end supports
$b_M$	$0.5 \cdot l_{eff}$	$0.25 \cdot l_{eff}$
$b_{Ms}$	$0.25 \cdot l_{eff}$	$0.125 \cdot l_{eff}$
$b_Q$	$t + d$	$t + 0.5 \cdot d$

- $b_{Mf}$  effective width in the span area of the flush girder
- $b_{Mf}$  effective width in the support area of the flush girder
- $b_{Mf}$  effective width for the shear design of the flush girder
- $l_{eff}$  structural length. The structural length is determined by multiplying the clear width  $l_n$  with the factor 1.05.

**Effective widths and loaded areas**



The loaded areas are determined by the 60° lines drawn from the theoretical support points and by the centre lines of the respective slab spans. Optionally, you can simplify the calculation by using the half of the slab support distance.


**Additional reinforcement at the slab end support**

The required transverse stirrup reinforcement is determined as follows:

$$\text{req. } a_{s_{\text{trans}}} = h[\text{cm}] / 10[\text{cm}^2/\text{m}] \text{ reinforcement ratio of } 0.1 \%$$


The transverse reinforcement is to be laid over the effective support distance plus 0.2  $l_{\text{eff}}$ .

The existing span reinforcement transverse to the discontinuous support is to be installed up to the unsupported slab edge.



**Additional reinforcement at the interior support**

The span and support reinforcements are to be laid over the entire effective length. If the length exceeds  $l_{\text{eff}} > 10 d$ , the support reinforcement is to be increased linearly up to  $\leq 15 d$  by 40 % in the area of 0.4  $l_{\text{eff}}$ .





## Output

You can optionally include durability in the output.

Description of the output: [FDC - Output and printing\\_eng.pdf](#)

## Reference literature

- /1/ DIN EN 1992-1-1 / NA Amend.1:2012-06
- /2/ ÖNORM B 1992-1-1:01/12/2011
- /3/ Booklet 240 of the German Committee for Reinforced Concrete DAfStb