


Steel Bracing ST12+

FRILO Software GmbH

www.friilo.com

info@friilo.eu

As of 29/11/2017



Steel Bracing ST12+

Contents

Application options	4
Basis of calculation	5
Loading	5
Bracing in accordance with Petersen	5
Bracing as per DIN EN 1993-1-1	5
Verification of the diagonal tension struts and of the compression members	5
Basic parameters	6
Structural system	7
Loading	8
Design	10
Output	10

Further information and descriptions are available in the relevant documentations:

Basic Operating Instructions-PLUS	General instructions for the manipulation of the user interface
FDC – Menu items	General description of the typical menu items of Frilo software applications
FDC – Output and printing	Output and printing
FDC - Import and export	Interfaces to other applications (ASCII, RTF, DXF ...)
FCC	Frilo.Control.Center - the easy-to-use administration module for projects and items
FDD	Frilo.Document.Designer - document management based on PDF
Frilo.System.Next	Installation, configuration, network, database

Application options

The software is suitable for the structural calculation and design of bracing typical in the construction of portal frames:

- Diagonal tying with compression slack diagonal steel struts for buildings with trussed girders

Available standards

The internal forces are determined in a second-order analysis with consideration of the failure of the diagonal compression struts. The approach to imperfections is based on the following optional solution methods:

- DIN EN 1993
- BS EN 1993
- ÖNORM EN 1993
- Petersen

For the diagonal tension struts a verification of the cross section is performed and for the compression posts in addition a stability analysis.

A verification of the chord for the additional axial chord force is not performed in this software.

Reference literature

- /1/ DIN EN 1993-1-1
- /2/ Petersen: Stahlbau (1990, 2nd improved edition, Braunschweig/ Wiesbaden, Publisher Vieweg & Sohn
- /3/ DIN 4114: Steel construction; stability cases (buckling, tilting, bulging), design principles, guidelines, 1953

Basis of calculation

Loading

For the calculation of the internal forces of the braces the following loads and forces are to be considered:

- the wind load at the height of the bracing
- the compressive chord forces of all roof trusses

The axial chord forces are γ -fold results of a previous frame and girder calculation. The γ -fold equivalent load for the bracing system is calculated from the axial chord forces. The bracing system itself is designed for this equivalent load and the additional γ_w -fold wind load.

Additional loads in the bracing plane can be considered in the software.

The user can specify the axial force in the compression chord or have it calculated from the internal forces by the software.

The calculation of the axial chord force for double-symmetrical I-shapes is based on /3/:

$$N_{\text{Gurt}} = \sigma_{\text{d}} \left(h_{\text{t}} \cdot t_{\text{f1}} + \frac{1}{5} A_{\text{w}} \right) - \frac{N_{\text{Ed}}}{2}$$

Second-order influences must be considered in the design of the bracing system.

To do this, assumptions concerning the imperfections have to be made. Because the consideration of imperfections is not clearly defined, you can find different relations in literature.

Bracing in accordance with Petersen

Petersen replaces the laterally pre-deformed chords with a hinged bar chain. The deviation forces are applied to these hinges.

They are included as node loads acting on the truss. The internal forces are calculated in a second-order analysis with consideration of the failure of the compression members.

The approximation formulae by Petersen apply only to truss systems with a constant span length.

The calculation is based on the initial imperfection $e = \frac{L}{500}$.

Bracing as per DIN EN 1993-1-1

The stabilizing equivalent forces are calculated as constant UDL* as per DIN EN 1993-1-1, 5.3.3.

The internal forces are calculated in a second-order analysis with consideration of the failure of the compression member.

Verification of the diagonal tension struts and of the compression members

The verification of the cross-sectional resistance is based on the internal plastic limit forces. Optionally, a stress analysis based on the elastic model can be performed.

For the compression members, the stability verification is performed in accordance with DIN EN 1993-1-1, 6.3.1.

* uniformly distributed load

Basic parameters

Standard and safety concept

Selection of the standard:

- DIN EN 1993
- BS EN 1993
- ÖNORM EN 1993

γ_G :

Check this option if all permanent loads or load cases shall be included with the same partial safety factor ($\gamma_{G,sup}$ or $\gamma_{G,inf}$). Otherwise, all permanent loads or load cases are combined with each other with ' $\gamma_{G,sup}$ ' and ' $\gamma_{G,inf}$ '.

Structural safety

Cross-section design

optional selection whether the design of the cross section should be based on the elastic model as per equation 6.1 or on the plastic model as per equation 6.2.

The screenshot shows a software interface with a 'Properties' panel on the left and a 'Design Standards and Safety Concept' table on the right.

Properties

- Basic Parameters
- System
- Loads
- Output

Design Standards and Safety Concept

Design Standard	BS EN 1993:2008
Combination equation	(6.10)
equal γ_G for all permanent loads	<input type="checkbox"/>
Ultimate Limit State	
Cross-section design	plastic

Structural system

Material

Selection of the steel type and grade for the chords, posts and diagonals.

Structural system

Spans	allows you to specify how many cross beams there are in total.
Bracing length	total length of the bracing.
Individual span length	equal span length is the default setting. Via the button  , you can access the dialog to enter an individual span length. The calculation method described by Peters applies only to structural systems with equal span lengths!
Height	the height of the bracing corresponds to the distance of the girders.

Select/define cross section

You can select cross sections separately for the horizontal, vertical and diagonal members from the Frilo Profile Library

You can also define a cross-section by selecting 'User-defined'.

The button  allows you to access the dialog for the selection of the steel cross-section.

See also the document ▶ [Selecting/Defining Cross-Sections - PLUS.pdf](#)

Girders	you can select among I-shapes and I-shapes with inclined flanges.
Posts	in addition to I-shapes and I-shapes with inclined flanges, rectangular and round hollow sections are available.
Diagonals	in addition to the shapes available for girders and posts, round steel, flat steel and thin-walled open profiles are available for selection. For open profiles, you need to define the dimensions

Properties	
Basic Parameters	
System	
Loads	
Output	
Material	
Type	structural steel
Grade	S235
System	
Modules	4
Diaphragm length	[m] 18.00
Individual span length	(4) 
Height	[m] 3.00
Girder	IPE 600 [90°] 
Post	RO 114.3X2 
Rotated post	<input type="checkbox"/>
Diagonal struts	RND 30 
Diagonals rotated	<input type="checkbox"/>
Remarks	
... System	

Loading

You can access the respective input dialogs via the button .

Border conditions

The following options are available to access the input window:

Building/Load Parameters

- Altitude above ground level the altitude of the bracing above the ground level; the wind pressure is calculated for this height level.
- Girders number of girders in the building.
- Braces number of braces acting together
- Affected height the affected height relating to wind action on the bracing plane. The calculated wind pressure is multiplied with this value.

Construction / load parameters		
Boundary conditions		
Location over the terrain surface	[m]	10.00
Girder		10
Girder spacing	[m]	3.00
Length of the building	[m]	27.00
Diaphragm		2
Influence height	[m]	5.00

Wind

Select the federal state and the municipality from a list to determine the associated wind zone as well as the altitude above MSL.

You can uncheck this option, however, to specify these values in the subsequent dialogs.

The corresponding dialogs are only enabled when you uncheck the municipality selection option.

Selection of the wind zone.

Selection of the terrain category.

Basic wind speed/basic wind pressure:

- Slope H/Lu value 'H/Lu' in flow direction with 'H' for the height of the slope and 'Lu' for the length of the slope, see also EN 1991-1-4, A.3 (1).
On isolated mountains, mountain chains or rocks, different wind speeds result from the slope of the ground surface.

- Orography factor factor as per EN 1991-1-4, figure A.2 for cliffs or offsets in the ground surface or A.3 for hilltops and hill crests, related to the effective length 'Le' of the windward gradient.

Properties		
Basic Parameters		
System		
Loads		
Output		
Boundary conditions		
Construction / load parameters		
Wind		
Distribution of wind load as		Uniformly distributed load
Wind suction on lower chord		<input type="checkbox"/>
Stabilizing equivalent forces		
Flange force	Nd	[kN] 290.1
Preforming	I/	500
Distribution as		EN1993-1-1(Uniform load)
Load Cases		
Standard Load Cases		To the table
Additional LC		To the table
Load Case Control		
Load case active		...
Load case control		Notice
Remarks		
... Actions		

Eingabe der Randbedingungen zur Ermittlung der Windlasten		
Gemeinde Wind Geometrie Windlasten		
Standort		
Gemeinde		Ludwigsburg
Geländehöhe	hNN [m]	278

Gemeinde Wind Geometrie Windlasten		
Wind Grundwerte		
Windzone		1
Geländekategorie		Kategorie II
Basiswindgeschwindigkeit	vb0 [m/s]	22.50
Basisgeschwindigkeitsdruck	qb0 [kN/m²]	0.32
Wind Beiwerte		
Geländeneigung H/Lu	phi	1,000
Orographiefaktor	s	1,000
Topographiebeiwert	co	1,600
Windlast		
Geschwindigkeitsdruck (h=0.0)		[kN/m²] 1.54

Topography coefficient indication of the coefficient as per EN 1991-1-4, 4.3.3. At places where the topography (e. G. mountains, cliffs etc.) increases wind speed by more than five percent, the speed increase is to be considered via the topography factor 'co'.

Wind pressure (h=0) the dynamic wind pressure at the altitude of 0.0 m can be modified for further calculations.

You can select whether the wind load should apply as a uniformly distributed load or as a node load. As a standard, wind pressure and suction are applied to the top chord.

Stabilizing equivalent forces



Chord force bracing loads are calculated from 'Nd' using the method described by [Petersen] or as per DIN EN 1993-1-1, 5.3.3. You can either enter the axial force in the chord directly or have it calculated by the software. The calculation is based on 'Nd' and 'Md' which you can specify for the upright member by clicking

on the editing button .

'Nd' is the existing axial force in the girder (axis).

'Md' is the existing moment in the girder, used to calculate the chord force.

Initial imperfection I/500 indication of the imperfections of the supported girders.




Load cases

Standard load cases

The default load cases are 'wind on gable' and 'equivalent forces'. They are generated automatically from the defined system data, the border conditions and the axial chord force. They cannot be edited but you can disable them via the 'Load case active' option.

Additional load cases

Additional load cases are registered in the table. Loads can be entered in a table or in the graphic and be edited there.



Design

Click on the "Calculate" button. After completion of the calculation, the utilizations are displayed.

Output

Via the 'Results' tab (on top) you can display the different result graphs.



The 'Output' menu item allows you to define the desired scope of data to be put out by checking the corresponding options.

The output document can be accessed by clicking on the 'Document' tab (above the graphic screen).

